



CORTAC™

CTAV™ Retrofit Instructions for Tactical and Concealable Armor

Make sure carrier is completely dry. Install the hook tape 24 hours before wearing armor. Repeat steps 1 - 4 for the front and back armor carrier.

1



Lay armor on flat surface to expose torso-facing side of the armor carrier.

2



Inflate the CTAV panel and check for proper placement on the carrier. Remove the CTAV panel and go to step 3.

3



Peel the hook tape from the plastic and place onto carrier*. Use the plastic film to push the hook tape firmly onto the carrier.

4



Place the CTAV panel onto the carrier. Be sure to align the CTAV so it has at least a 1 in. space between edge of CTAV and edge of the armor carrier.